


Lumecel PI Demo Instructions


Date: 12/6/2019

1. Attach pi screen to pi
2. Attach automation hat to pi
3. Supply power to screen




5. Black wire => ground; Red wire 5v
6. Attach to 5v and ground on automation hat

7.




8. Load supplied image to sd card and insert into pi
9. Attach ribbon cable to pi and pi screen
10. Open RCP dispenser and unplug Lumicel plug


11.



12. Use hookup wire or similar wire to wire plug into pi. Can also use open ended adapter if one is available.




14. Purple to ADC 1 (see below)



16. Grey to ground

17. Yellow and black are joined. I used alligator clip wire



19. Plug pi in

20. Will auto load web server and full screen web page

